



Quality Frame Tents for Rental and Commercial Industries

CALL US: 800-997-8368

EMAIL: sales@centraltent.com

Georgia Location: 889 Industrial Blvd Ringgold, GA 30736

Texas Location: 5911 Hamblen Dr, Humble, TX 77396, United States



10x20 Standard Frame Tent			
Qty	FITTINGS		Part #
4	Corner		C1001
2	3 Way Crown		C1004
2	Side Tee Joint		C1003
1	Ridge Slide Tee		C1010-2
38	Canopy Pins		P102
Qty	Size	Poles	Color
7	9'-4"	Spreader	White
4	6'-10"	Hip Rafter	Yellow
2	4'-11"	Rafter	Blue
6	7'-8"	Legs	Black

10x20 STANDARD HIP END - FRAME TENT

INSTRUCTION :

1. Lay out four (4) corner fittings, two (2) tee fittings, and six (6) (White 9' 4") spreader pipes, and form a perimeter frame. Assemble and insert pins.
2. Put one (1) (White 9' 4") spreader pipe, and two (2) 3-way crown fittings into the center of the frame. Slide two (2) adjustable slide fittings to the center of the spreader pipe.

3. On one end, insert one (1) (Yellow 6' 1 O") hip rafter into the corner fitting and pin. Then insert the opposite end of the hip rafter into a 3-way crown fitting and pin. Insert one end of another hip rafter into the same 3-way crown fitting and pin. Then insert the opposite end into the corner fitting and pin.
4. Insert one end of the center spreader into the assembled 3-way crown fitting and pin.
5. Insert one end of the side rafter (Red 4' 11 ") into the side tee fitting and pin. Insert the opposite end into the slide fitting on the center spreader and pin. Repeat on the opposite side.
6. Repeat steps 3 and 4 to complete the remaining end of the frame.
7. Place the canopy over the frame and pull tight—a secure canopy to frame with buckle straps, tightening corner buckles first.
8. Raise one side of the canopy; insert leg pipes (Black 7'8") into the corner, tee fittings, and pin.
9. Raise the opposite side of the canopy and install the remaining legs.
10. The canopy and frame can now be tied down.

Caution; tie down only at corner or tee fittings. Do not tie to the spreader pipe as they may bend.