

Quality Frame Tents for Rental and Commercial Industries

CALL US: 800-997-8368

EMAIL: sales@centraltent.com

Georgia Location: 889 Industrial Blvd Ringgold, GA 30736

Texas Location: 5911 Hamblen Dr, Humble, TX 77396, United States



| 10x40 Standard Frame Tent | | | |
|---------------------------|----------------|--------------|--------|
| Qty | | FITTINGS | Part# |
| 4 | Corner | | C1001 |
| 2 | 3 Way Crown | | C1004 |
| 6 | Side Tee Joint | | C1003 |
| 3 | Ridge Top Tee | | C1008 |
| 1 | 10 Ft. Cable | | CB10X |
| 68 | Canopy Pins | | P102 |
| | | | |
| Qty | Size | Poles | Color |
| 12 | 9'-4" | Spreader | White |
| 4 | 6'-10" | Hip Rafter | Yellow |
| 6 | 4'-11" | Rafter | Blue |
| 2 | 4'-4" | Top Spreader | Red |
| 10 | 7'-8" | Legs | Black |
| | | | |

10x40 STANDARD HIP END - FRAME TENT

INSTRUCTIONS:

- 1. Layout four (4) corner fittings, eight (8)(white 9°4"), and (4) (4 '4") spreader pipes and form a perimeter frame. Assemble nails or pins.
- 2. Assemble three (3) (white 9'4*) spreader pipes into two (2) top tee fittings, and two (2) 6-way crown fittings into the center of the frame.

- 3. On one end, insert one (1) yellow (6'10*) hip rafter into corner fitting and nail. Then insert the opposite end of the hip rafter into a 6-way crown fitting and nail. Insert one end of another hip rafter into the same way fitting and nail.
- 4. On the same end, insert one (1) (red 4°1 1") rafter pipe into the same 6-way fitting and nail. Do the same for the opposing side.
- 5. Repeat steps 3 and 4 for the other end. Insert one end of the center spreader into the assembled 3-way crown fitting and nail. Insert one end of the side rafter (red4'11") into the side tee fitting nail. Do the same for the Opposite. Repeat for all rafters.
- 8. Place the canopy over the frame and pull tight. Secure the canopy to the frame with buckle straps, tightening the corner buckle first.
- 9. Raise one side of the canopy, insert leg pipes (black 7'8") into the corner, and tee fittings and nails.
- 10. Raise the opposite side of the canopy and install the remaining legs.
- 11. The canopy and frame can now be tied down.

Caution tie down only at the corner or tee fittings. Do not tie to the spreader pipe as they may bend.